Here's the full installer from the vendor:

https://clearcom.ftpstream.com/50396/bae8b5d8fc6ea4009fc143557087dd9e/AE/Erik/dapi-4.2.3.2 windows.exe

These are looking for specific hardware devices on the network, so if you need to remote into a development machine for them, that can be arranged.

First - from dante_browsing_test:

If it Is run with the -conmon argument, we wait for the connection to proceed, I can type r d and list all devices:

```
Administrator: Command Prompt - dante_browsing_test.exe -conmon
                                                                                                                                                                 X
C:\Program Files (x86)\Audinate\Dante API\examples\bin\Debug\Win32>dante_browsing_test.exe -<mark>conmon</mark>
WARNING: Quick edit mode is enabled for this console. Highlighting text in the console window while this application is
running will stall the application. This can lead to timeouts and other unexpected DAPI events.
Created environment
Current domain configuration:
 omain Handler Summary:
  State: DISABLED
  Current domain: ADHOC
  Available domains:
     ADHOC
Running main loop
> Network changed
Network changed
Network changed
Reconfirming device 'Clear-Com-Intercom'
Reconfirming device 'DESKTOP-VSC'
Reconfirming device 'WIN-59B9F8QNN58'
```

There's a for loop that goes through each indexed device. I want all those names.

By searching for the main() entry point and copying the code used after -conmon is detected, and then by hooking up to "Network changed" and copying the for-loop that outputs "Reconfirming device" I've

been able to create an executable that can run this test without input, but short of using Process.Start, I can't consume it from an ASP.Net project.

I also want to be able to call the equivalent of p and discover AES67 flows:

```
> p
No AES67 flows discovered
```

Second – from dante_routing_test

This is what I'd like to replicate without the command line – if I launch the application, passing in a device name:

```
C:\Program Files (x86)\Audinate\Dante API\examples\bin\Debug\Win32>dante_routing_test.exe DESKTOP-VSC dante_routing_test.exe: Routing API version 4.0.0
Current domain configuration:
Domain Handler Summary:
State: DISABLED
Current domain: ADHOC
Available domains:
```

By hitting Enter, I can get a prompt, which allows me to do r, a number, then a new name string. I also get a confirmation:

```
Type '?' for help

'DESKTOP-VSC'> r 8 "NEW-NAME"

ACTION: Set Rx Channel Name
Setting RX channel 8 name to "NEW-NAME"

EVENT: device changed: STALE= RXCHANNELS
Active Requests: 1/16

'DESKTOP-VSC'>
EVENT: completed request 01559C00 (SetRxChannelName) with result success
```

By hitting r, I get all RX channels – I want this whole list:

```
'DESKTOP-VSC'> r
                                                               Format
48000/[*24->0x000e]
   ID Name
                                                                                                                                                                                  Subscription
01@Clear-Com-Intercom
                                                                                                                                                                                                                                                                                                                          Flow ID
                                                                                                                       Latency Mute
                                                                                                                                                               dBu
                                                                                                                                                                                                                                                                     Status
                                                                                                                       6000
                                                                                                                                                                                                                                                                     DYNAMIC
                                                                                                                       6000
                                                                                                                                              false
                                                                                                                                                                                   02@Clear-Com-Intercom
                                                                                                                                                                                                                                                                     DYNAMIC
         03
04
                                                                                                                                              false
                                                                                                                                                                                  03@Clear-Com-Intercom
04@Clear-Com-Intercom
05@Clear-Com-Intercom
                                                                                                                       6000
                                                                                                                                                                                                                                                                     DYNAMIC
                                                                                                                      6000
                                                                                                                                              false
                                                                                                                                                                                                                                                                     DYNAMIC
                                                                                                                                               false
                                                                                                                                                                                                                                                                     DYNAMIC
         06
07
                                                                                                                       6000
                                                                                                                                                                                   06@Clear-Com-Intercom
                                                                                                                                                                                                                                                                     DYNAMIC
                                                                                                                                              false
                                                                                                                                               false
          NEW-NAME
                                                                                                                                               false
  9 09
10 10
11 11
12 12
13 13
14 14
15 15
16 16
                                                                                                                                              false
false
                                                                                                                                               false
                                                                                                                                              false
                                                                                                                                              false
                                                                                                                                               false
   17 17
18 18
                                                                                                                                               false
                                                                                                                                               false
```

Similarly, I need t:

```
'DESKTOP-VSC'> t
 TX Channels for device DESKTOP-VSC:
                                                         Format

48000/[*24->0x000e]

48000/[*24->0x000e]
   ID Name
                                                           Format
                                                                                                            Enable Mute
                                                                                                                            false
                                                                                                           true
         02
                                                                                                                            false
                                                                                                            true
         03
                                                                                                                            false
                                                                                                            true
         04
                                                                                                                            false
                                                                                                            true
          05
                                                                                                            true
                                                                                                                            false
         06
                                                                                                                            false
                                                                                                            true
                                                                                                                            false
                                                                                                            true
         08
                                                                                                            true
                                                                                                                            false
                                                                                                                            false
         09
                                                                                                            true
                                                                                                                            false
   10 10
                                                                                                            true
   11 11
                                                                                                                            false
                                                                                                            true
   12 12
                                                                                                                            false
                                                                                                            true
   13 13
                                                                                                            true
                                                                                                                            false
   14 14
                                                                                                                            false
                                                                                                            true
   15 15
                                                                                                                            false
                                                                                                            true
   16
         16
                                                                                                            true
                                                                                                                            false
```

I need to be able to pass in s, a number, then a name, and get a result:

```
'DESKTOP-VSC'> s 9 "09@CLEAR-COM-INTERCOM"

ACTION: Subscribe

EVENT: device changed: STALE= RXCHANNELS
Active Requests: 1/16

EVENT: device changed: STALE= RXCHANNELS RXFLOWS
Active Requests: 1/16

'DESKTOP-VSC'>
EVENT: completed request 0155C360 (Subscribe) with result success
```

I need to be able to access the function that I does on the command line to list labels:

```
'DESKTOP-VSC'> 1

1: "01"
2: "02" "SOME LABEL"
3: "03"
4: "04"
5: "05"
6: "06"
7: "07"
8: "08"
9: "09"
10: "10"
11: "11"
12: "12"
13: "13"
```

Finally, I need to be able to do the same a I, a number, a name and +, then get back the result:

```
'DESKTOP-VSC'> 1 1 "NEW-LABEL" +

ACTION: Add Tx Label
Adding label "NEW-LABEL" to tx channel 1

'DESKTOP-VSC'>
EVENT: completed request 01558580 (AddTxLabel) with result success

EVENT: device changed: TXLABELS
Active Requests: 0/16
```